

## Combination Code

A

After establishing the combination code using the app, you can put the Bitlock into combination mode by holding either of the buttons on the Bitlock for 3 seconds.



B


Once in combination mode, the blue LED begins to blink fast, indicating that Bitlock is ready to be unlocked using the combination code.

C

Choose either of the buttons to enter the combination as a sequence of button presses (for example, digit 3 translates to 3 button presses), and switch to the next button to enter the next digit. Once the 4 digits are entered, press the next button to indicate that you are done to see BitLock open.

### Example

The example below illustrates the sequence of operations needed to enter the combination code "3242" to unlock BitLock:



### Note

Please refer to a set of tutorial videos that are located inside the app under Settings -> Tutorials for more

 Check out BitLock channel for tutorial videos

 Tweet to us: #getbitlock

 facebook.com/getbitlock

 support@bitlock.co

 <http://www.bitlock.co>

 <https://bitlock.zendesk.com>



**BITLOCK**

**LOCK**



**ONE LOCK FOR ALL**


1

Install the BitLock application from App Store on iPhone and Google Play on Android.




2

After registering and signing into your account, press either of the buttons on BitLock to initiate the lock registration process on the app.



3

Follow the instructions that appear on your phone and set a name and combination code for your lock to complete the registration process



### Note

The digits in the combination code must be between 1-9. Zero is not accepted by design.

### IMPORTANT !

The lock will not unlock if there is tension between the U-bar and the base! It is recommended to always hold both the U-bar and the base when unlocking. If necessary, provide counter pressure to ensure the unlocking mechanism can function.


4

Press either of the buttons on BitLock to lock/unlock. Both buttons serve the same function unless in combination mode.




5

Put the U-bar back in place after removing it as shown below.



6

Press either of the buttons again to lock back.



### Note

To save battery life BitLock enters power saving mode 20 seconds after the last interaction with the lock (any button presses). To wake up the lock, you must press either of the buttons again before you can lock and unlock.

### Lock Status Indication



Fast Blink Blue: Authenticating user



Slow Blink Blue: Searching for phone



Solid Red: Locked



Solid Green: Unlocked